

Available Gasket Kits from Cat

Fuel System – This kit contains the gaskets, seals, and bendable locks to rebuild and reinstall the engine mounted fuel system components. This kit does not include injector seals; these seals are located in the single fuel injector kit.

Front Structure – This kit contains gaskets, seals, and bendable locks to reinstall the front housing, covers and attachments located on the front housing. This kit does not include the oil pan gasket; this gasket is located in the central and lower structure kit.

Central and Lower Structure – This kit contains gaskets, seals, and bendable locks to reinstall the oil pan, internal oil pump, block covers, and oil and water lines located on the cylinder block and oil pan. This kit does not include components required to rebuild any internal oil pumps.

Aftercooler and Lines – This kit contains the gaskets and seals to install the aftercooler, and the seals required to reinstall the water lines and oil lines to the aftercooler.

Cylinder Head – This kit contains the gaskets, seals and bendable locks required when rebuild the head and reinstalling the head. For multiple cylinder head engines there are multiple cylinder head kits and single cylinder head kits available. This kit does not include injector seals; these seals are located in the single fuel injector kits.

Oil cooler and Lines – This kit contains the gaskets and seals to assemble and reinstall the oil cooler(s), oil filter base and associated oil lines.

Oil Pump – This kit contains gaskets, seals, and bendable locks to reinstall external oil pump only. The kit does not include components required to rebuild the oil pump.

Rear Structure – This kit contains gaskets, seals, and bendable locks to reinstall the flywheel housing, covers and accessories located on the flywheel housing. This kit does not include the oil pan gasket; this gasket is located in the central and lower structure kit.

Single Cylinder Liner – This kit contains the seals to reinstall one cylinder liner. The kit does not include the piston rings. They will need to be purchased individually.

Single Fuel Injector – This kit contains the seals needed to reinstall one injector into the cylinder head.

Turbocharger Installation – This kit contains the gaskets and seals to reinstall the turbo(s) and attaching lines. The turbo mounting hardware is included in the kit for kits developed after kit part number 317-8751 and higher.

Water Lines Group – This kit contains the gaskets and seals to install a water lines group. This kit is available for the 3408, 3412, 3500, 3600, C175 engine models only.

Water Pump Installation – This kit contains the gaskets and seals to reinstall the water pump and water lines. The kit does not include any of the component required to rebuild the water pump.

Expansion Tank – This kit contains the gaskets and seals to reinstall the expansion tank or heat exchanger.

Air Compressor Installation – This kit contains the gaskets, and seals to reinstall the air compressor, , and associated water and oil lines attached to the air compressor. The kit does not include any of the components required to rebuild the air compressor.

Exhaust Manifold – This kit contains the gaskets and seals to reinstall dry or water cooled exhaust manifolds and associate water lines where required. This kit is available for the 3408, 3412, 3500, 3600, C175 engine models only.