

Section 4

Wire / Hose Routing

CONTENTS

Precautions	4-1	Wiring Harness Routing Diagram.....	4A-3
Precautions.....	4-1	Fuel / Water Hose Routing	4B-1
Precautions for Wire / Hose Routing	4-1	Precautions.....	4B-1
Component Location	4-1	Precautions for Fuel / Water Hose Routing.....	4B-1
Electrical Component Location	4-1	Schematic and Routing Diagram	4B-2
Wire Routing	4A-1	Fuel Hose Routing	4B-2
Schematic and Routing Diagram.....	4A-1	Water Hose Routing.....	4B-5
Wiring Diagram	4A-1		

Precautions

Precautions

Precautions for Wire / Hose Routing

Refer to “General Precautions” in Section 00 (Page 00-1).

CENDK1114000001

Component Location

Electrical Component Location

Refer to “Wiring Harness Routing Diagram” in Section 4A (Page 4A-3).

CENDK1114003001